

How to access your Kyocera copier's meter readings:

Copier Model - 1620/1635:

- Press and hold the clear button.
- When the start button lights up press it.
- The status page will be printed.

Copier Model - 1650/2050/2550:

- Press system menu/counter button located on upper left side of the copier's main operation panel.
- Scroll down to counter.
- Press Ok to print status page.

Copier Model – 3050/4050/5050

- Press counter button located on upper left side of the copier's main operation panel.
- Press print status page. & 250ci / 300ci / 400ci

Copier Model – 3035/4035/5035/6030/8030

- Press system menu/counter button located on upper left side of the copier's main operation panel. Press counter check all the way to the right on the LCD screen. Press print report.

Copier Model – 2560/3060/2540/3040

- Press counter button located on upper left of side of the copier's main operation panel.
- Press yes to print status page.

Copier Model – 1820

- Press system menu counter button.
- Scroll down to report.
- Press enter.
- When you see report print press enter.
- Scroll to status page.
- Press enter.
- Then press yes.